

Fork-King Modification for Smaller bikes

If you are unable to position the Fork-King between your front tyre and underside of fender/mudguard due to the height then you are able to cut it to length.

1. Measure from your front tyre to under the fender/mudguard (where the fork-king will be positioned).
2. Determine below which category your measurement falls into.

3. Using a hacksaw or appropriate cutting device, cut the outer shaft (grey) on the lower side of the ring of the corresponding number (**please ensure that the inner threaded shaft is not inserted when cutting**). See Figure 1

Measurements (shortest to longest length the fork support will go to):

240mm—350mm (9 ½ in – 13 ¾ in)	Full Size
205mm—300mm (8 in—11 ¾ in)	⑤
170mm—250mm (6 ¾ in— 9 ⅝ in)	④
135mm—190mm (5 ⅜ in—7 ½ in)	③
100mm—135mm (4 in— 5 ⅝ in)	②

4. Once you have cut the outer shaft (grey) you will then need to cut the below measurement from the top of the inner shaft (blue). See Figure 2.

35mm (1 ⅜ inches)	⑤
70mm (2 ¾ inches)	④
105mm (4 ⅛ inches)	③
140mm (5 ½ inches)	②

Disclaimer: please ensure safety precautions are taken when using cutting devices. We take no responsibility for Fork-Kings which are incorrectly altered or incorrectly positioned. We take no responsibility for any injury or property damage sustained directly or indirectly from the modification to or use of for a Fork-King fork support.



Figure 1

Figure 2
Inner Shaft